

CT SCALE OPERATION MANUAL

Thanks for your purchasing our products. This scale is of easy operation. Before using, please carefully read this manual.

SPECIFICATION:

g	oz	ct	ozt	dwt
20g/0.001	0.7055oz/0.0001oz	100.00ct/0.005ct	0.6430ozt/0.0001ozt	12.860dwt/0.001dwt

3 minutes of auto power off:

Operation temperature:

10-30°C

LCD display:

5 digits LCD display

Backlingt:

Blue Backling (optional)

Power:

2 X AAA batteries

Size:

99X88X25mm

Weight:

105g

Size of stainless steel pan: 34X34X5MM

Tare function

MODE: g/oz/ozt/dwt/ct/gn

ON/OFF:

PCS:

TARE:

(1) Operation:

Put the scale onto a flat surface. Press "ON/OFF", wait for 5 seconds till it shows "0.0". Put the object onto the pan. When the "s" shows on left up, the scale is showing the weighing value of the object.

(2) How to calibrate

Hold the ON/OFF key and press the MODE key 4 times at the same time then a series of inner code will display on LCD, press the MODE key after it is stable, you can only put a 20g weight on the scale when the LCD says 20g, then press MODE key to confirm, you will see PASS if you have done these actions correctly.

(3) Counting function

In the situation of weighing, put the sample object on scale, hold the PCS key for 3 seconds, then you can see 25, 50, 75, 100 shining in turn, press the MODE key to choose the number, press the PCS key again to confirm, then back to counting situation, it will show the quantity of these samples. Press the MODE key so that you can back to weighing.

Remark:

Take off cover lightly and carefully when use. Put the scale on a stable, flat surface without shaking, wind influence.

Don't put heavier object than the capacity of the scale onto the pan. This can give damage to the load cell. Don't strike the pan of the scale. Handle with care.

Don't use mobile phone within 50 cm distance to the scale. This can influence the accuracy of the scale. When the "O" shows on the left up, the scale is showing the weighing value.

please replace the battery as soon as you see a Lo in display, make sure that your battery is a good one. Please use this scale under the temperature of 10-30°C. Make sure that this scale has been placed at this situation above 30 minutes

When the object weight is over the capacity of the scale, it shows "ERR" mark.

Please keep this scale with care.

CARAT SCALE USER MANUAL

